



Master-Satellite

# User manual



THIS PAGE HAS BEEN INTENTIONALLY LEFT BLANK

# **Master-Satellite User Manual**

## **COPYRIGHT INFORMATION**

This document is copyrighted, 2023 by Circontrol, S.A. All rights are reserved. Circontrol, S.A. reserves the right to make improvements to the products described in this manual at any time without notice.

No part of this manual can be reproduced, copied, translated or transmitted in any form or by any means without the prior written permission of the original manufacturer. Information provided in this manual is intended to be accurate and reliable. However, the original manufacturer assumes no responsibility for its use, or for any infringements upon the rights of third parties that may result from its use.

All other product names or trademarks are properties of their respective owners.

CIRCONTROL reserves the right, in its discretion, to make any amendments, corrections or changes to this manual and its contents at any time, without obligation to give prior notice.



# Here's your guide to use and configure your Master-Satellite solution

|                                     |           |
|-------------------------------------|-----------|
| <b>1- So, hello!</b>                | <b>06</b> |
| <b>2- Features</b>                  | <b>08</b> |
| <b>3- How to use it?</b>            | <b>12</b> |
| A- General                          | 12        |
| B- Language                         | 14        |
| C- Starting a charging session      | 15        |
| D- Special events starting a charge | 18        |
| E- Stopping a charging session      | 20        |
| F- Charge information               | 21        |
| G- Charge summary                   | 22        |
| H- Emergency button                 | 23        |
| I- Connector status                 | 24        |
| J- Errors                           | 25        |
| <b>4- How to connect it?</b>        | <b>28</b> |
| A- Network topology                 | 28        |
| B- Introduction                     | 29        |
| C- IPSetup                          | 30        |

---

|                          |           |
|--------------------------|-----------|
| <b>5- Communications</b> | <b>34</b> |
| A- Introduction          | 34        |
| B- Modem configuration   | 35        |
| <br>                     |           |
| <b>6- Setup Webpage</b>  | <b>52</b> |
| A- Dashboard             | 52        |
| B- Monitor               | 54        |
| C- Historic              | 55        |
| D- Integrations          | 56        |
| E- Configuration         | 57        |
| F- Maintenance           | 72        |
| <br>                     |           |
| <b>7- OCPP1.6J</b>       | <b>76</b> |
| A- Introduction          | 76        |
| B- Before starting       | 77        |
| C- Configuration         | 78        |
| <br>                     |           |
| <b>8- Monitoring</b>     | <b>88</b> |
| <br>                     |           |
| <b>9- Technical Data</b> | <b>90</b> |
| A- AC Charge             | 90        |
| B- DC Charge             | 92        |
| <br>                     |           |
| <b>10- Need help?</b>    | <b>94</b> |

# 1

## So, hello!

---

This manual provides information about the usability and configuration of the Master-Satellite solution, which has been designed and tested to allow electric vehicle charging, specified in IEC 61851.

It contains all the necessary information for safe use and help to get the best performance from it with step-by-step configuration instructions.

### THE FOLLOWING SYMBOLS ARE USED FOR IMPORTANT SAFETY INFORMATION IN THIS DOCUMENT



#### ELECTRICAL RISK

Necessary precautions shall be taken to prevent any electrical risk while the operations are carried out within the unit.


Unit must be disconnected from any power source during commissioning.



#### ATTENTION!

Indicates that the damage to property can occur if appropriate precautions are not taken.

## IMPORTANT SAFETY INSTRUCTIONS



- Do not use the Charge Point for anything other than electric vehicle charging modes which are defined in IEC 61851-23.
- Do not modify the Charge Point. If modified, CIRCONTROL will reject all responsibility and the warranty will be void.
- Comply strictly with electrical safety regulations according to your country.
- Do not make repairs or manipulations with the unit energised.
- Only trained and qualified personnel should have access to the electrical parts inside the Charge Point.
- Check the installation annually by qualified technician.
- Remove from service any item that has a fault that could be dangerous for users (broken connectors, caps that don't close...).
- Use only Circontrol supplied spare parts.
- Do not use this product if the enclosure or the EV connector is broken, cracked, open, or shows any other indication of damage.
- Adaptors or conversion adapters and cord extensions set are NOT allowed to be used.
- The device does not emit noise, ultrasounds, electromagnetic fields and does not produce harmful substances, thanks to which it can be operated in the environment.
- Pay attention to traffic in busy streets.
- Waste generated after the disassembly of a waste device or a device taken out of service is handed over to a person conducting activity in the field of recycling or conducting activity in the field of recovery processes.

Refer to TECHNICAL DATA section for more information about environmental installation conditions.

# 2

## Features

---

### Master

Able to be configured for multi-point solutions.

- **HMI:** 8" colour touch screen as the interface between the Charge Point and the user. Provides detailed information about ongoing charge transactions and the instructions of how to interact with the Charge Point.
- **Connector Lock:** To avoid disconnection of EV meanwhile is charging.
- **Light beacon:** Three LED colour indicate all connector status (free, error, charging or completed) at a glance.
- **RFID Reader:** User authentication.
- **Ethernet:** TCP/IP communication for remote supervision and configuration.
- **4G Modem (optional):** For those places where wired communications are not enough.
- **Energy metering:** Integrated meter built is measuring power and energy consumed by the EV during a charge transaction.
- **Remote access:** For supervision and control from everywhere.
- **Charge transaction historics:** Charge Point is capable of storing information about the charge transactions.
- **OCPP:** Open standard communication protocol, allows communication between the Charge Point and the Central System.
- **Key lock access:** Security that does not enable access to the inside of the charger.
- **Built-in courtesy light\*:** Facilitates locating the charge point in dark areas and reading the operator instructions.
- **Integrated payment system (optional):** Availability for contactless card payment.

(\* Availability depending on the model



## Satellite

- **Connector Lock:** Available lock system to avoid disconnection of EV meanwhile is charging.
- **Light beacon:** Three LED colour indicate all connector status (free, error, charging or completed) at a glance.
- **Energy metering:** Integrated meter built is measuring power and energy consumed by the EV during a charge transaction.
- **Remote access:** For supervision and control from everywhere.
- **Charge transaction historics:** Charge Point is capable of storing information about the charge transactions.
- **Key lock access:** Security that does not enable access to the inside of the charger.


# Master-Satellite combination

The following table shows the possible combinations of Charge Point that can work as masters or as satellites:


| MASTERS                    | SATELLITES                     | TYPE OF CHARGE |
|----------------------------|--------------------------------|----------------|
|                            | Post/Wallbox eVolve Smart S    | AC             |
|                            | Post/Wallbox eVolve Smart T    | AC             |
|                            | Post/Wallbox eVolve Smart TM4  | AC             |
|                            | Post eVolve Smart C63 One      | AC             |
| Post eVolve Master S       |                                | AC             |
| Post eVolve Master T       |                                | AC             |
| Post eVolve Master C63 One |                                | AC             |
| Wallbox eVolve Master Zero |                                | AC             |
| Wallbox eVolve Master S    |                                | AC             |
| Wallbox eVolve MasterT     |                                | AC             |
|                            | Post eVolve Satellite S        | AC             |
|                            | Post eVolve Satellite T        | AC             |
|                            | Post eVolve Satellite C63 One  | AC             |
|                            | Wallbox eVolve Satellite S/T   | AC             |
| Raption 50                 |                                | DC             |
| Raption HV                 |                                | DC             |
| Raption HV EVO             |                                | DC             |
| Raption 100                |                                | DC             |
| Raption 150                |                                | DC             |
| Raption 150 Compact        |                                | DC             |
| Raption 200                |                                | DC             |
| Raption 400                |                                | DC             |
| Post eVolve Rapid Master   |                                | DC             |
|                            | Wallbox eVolve Rapid Satellite | DC             |
|                            | Post eVolve Rapid Satellite    | DC             |

# Outlets for each Master

We have different possibilities to be part of the Master-Satellite solution, with a maximum of 18 outlets, taking into account that 1 DC outlet equals to a 3 AC outlets.



The following picture shows some of the many possible combinations that can be part of the Master-Satellite solution\*:




(\* ) Number of Satellite outlets up to 18 AC.

# 3 How to use it?

## A) General


The first time the Charge Point is powered on, the system will take around 10 seconds to start up, the screen will show next image:



In the lower right corner, the firmware version is shown. After 10 seconds, the first screen that appears is the screensaver.



When tapping on the screen, the HMI will skip to the next one.\*



At this new screen, the Charge Point is asking for showing the identification method the user is going to use in order to start a charge transaction, as you can see there are four possible options.

- Choosing RFID or keyboard options, are the options that will let to initiate a 'Charging session' to the user that has the identification card, has been registered in advance or a code has been given to type it manually in the screen.

- Paying by a debit or credit card, that will let to initiate a 'Charging session' to the user without been registered in advance.

In the lower right corner, it shows the connectors status and the charging process so as to know the Charge Point availability.

**(\*) Depending on the optionals chosen, the identification methods available can vary.**



**Note: If some Charge Point do not have the latest firmware update, the term "slave" may appear instead of "satellite".**

## B) Language

During all the process is possible to change the language, pressing on the top of the screen over the **'Flag'** touch symbol:



The language can be chosen by tapping on the corresponding flag.




This option will allow user to change the language **ONLY** for the current Charge Transaction. When Charge Point returns to main or standby screen, it will return the default language, which is configured in the Setup Webpage.





**The availability of the different languages is subject to the firmware version.  
In case of doubt, please ask your local supplier.**

## c) Starting a charging session


Once the identification card is shown, it may take a few seconds to authorize the access.



The HMI informs if the access is granted or not.




If the user is authorized, the connector can be chosen.



*At any time it is possible to tap this button in order to go back to the "identification screen".*

Once the connector is chosen, instruction screens will appear successively.


### 1- Connect your vehicle and press the 'Start' button




*At any time is possible to tap this button in order to go back to the previous screen.*



## 2- Checking vehicle connection... Please wait




In a few seconds, the charging session will start and the HMI will show the charging process.




*Tap this button in order to go back to the "identification screen".*

## D) Special events starting a charge


**“Not authorized”**: some Charge Points could be working under the supervision of a main management system. If the user is not authorized, the HMI will show the following message:



**“Authorization failed”**: the authorization could not be completed due to some communication problem with the Back Office.




It is possible that the Charge Session could not be started due to some unexpected reason. The HMI will show next screen, press **'Retry'** button and try again.



## E) Stopping a charging session


After showing the same identification card that started the Charging Session, the Charge Point will automatically allow to stop the charging session, press over the **'Stop'** button:



Once the charging session is stopped, the HMI shows the summary screen.

# F) Charge information


Depending on the connector used, the HMI screen can show different process information. The information is almost the same except for few details.



- 1- Language button:** possibility to change the HMI language.
- 2- Additional information:** current status, errors, battery status, etc.
- 3- Connector information:** type and identifier of connector, power of charge, etc.
- 4- House touch button:** it goes back to the “identification screen”.
- 5- Charge time with status bar:** charging time elapsed so far.
- 6- Energy charged:** energy supplied to the vehicle so far.
- 7- Battery SOC\*:** it indicates the current battery state of charge.
- 8- Process indicator:** at first moment it is red, as the vehicle is charging it will change to orange, changing after 75% of battery charged to green.
- 9- Remaining time until 100 %\*:** remaining time until 100 % of the SOC.

(\* ) This information is only available in Raption and evolve Rapid series models.

## G) Charge summary



**1- Language button:** possibility to change the HMI language.

**2- Process instructions:** different instructions can be displayed.

**3- Energy charged:** total energy charged at the end of the charging session.

**4- Battery SOC\*:** It indicates the final battery state of charge at the end of the charging session.

**5- Exit button:** It has to be pressed in order to finish the charging session. After pressing, the HMI screen will go back to the "identification screen".

**6- Recharge time:** total recharging time at the end of the charging session.


**7- Information button:** pressing over this button you can get information about the charging session tariff applied.

**8- Stop reason:** It shows why the charging session has been stopped.


(\*) This information is only available in Raption and evolve Rapid series models.

## H) Emergency button

If for any reason the Emergency button is pressed, all in progress charge transactions will be stopped, the beacon lights will turn red and it will not be possible to start new charge transaction until the recovery process is completed successfully. All the power modules will shut down in order to protect the user and the own Charge Point. The HMI screen will remain powered up in order to show the instructions.










At first moment, the **'Restart'** touch button will be in light grey and it will not be able for pressing. Once emergency button has been unlocked, the **'Restart'** touch button will be in green and able to use.



# I) Connector status


The HMI screen shows different symbols, as you can see below:

|   |  |
|---|--|
|    | <p>Connector available, a Charging Session can be started.</p>   |
|    | <p>Connector charging, a Charging Session cannot be started because it is already in use.</p>  |
|    | <p>Connector disabled, a Charging Session cannot be started because it is under maintenance or because the Back office has decided to stop it.</p>                             |
|    | <p>Connector out of service, a Charging Session cannot be started due to some error.<br/>Tap on the <b>'Information'</b> button in order to get more information about it.</p> |
|  | <p>Connector reserved, a Charging Session can only be started using the IdTag assigned to the reservation.</p>   |
|  | <p>The Charge Point is out of service because the emergency button has been pressed. This fact affects all the connectors at the same time.</p>                                |
|  | <p>Applies when simultaneous charge is not available. In case, one connector is booked or already in use.</p>  |




## J) Errors


The Charge Point can report about different sort of errors, it can be from different parts or devices from it.



When the **'Error screen'** appears, the **'Information'** touch button has to be pressed in order to see the error message, as you can see below:



Logical levels:



**Charge point:** General errors affecting the whole charge Point (E.g.: RFID error).

**Plug:** Error affecting one plug. All sockets are in error state. Plug is inoperative.


**Socket:** One plug may have more than one socket. Error can affect one socket and plug still being available.

THIS PAGE HAS BEEN INTENTIONALLY LEFT BLANK


# 4

## How to connect it?

### A) Network topology



## B) Introduction



*The Ethernet port of the Master Charge Point is located at the bottom left side of the rear part of the HMI screen.*




*There is only one Ethernet port on the Satellite Charge Point and it is located on the TCPIRS. The location of this device may vary depending on the model, for more information please contact Circontrol Post-Sales Department.*

Before proceeding , make sure all the following is ready:



Computer running at least Microsoft Windows XP.



UTP Cable (at least one for each Charge Point)




IPSetup.exe (Can be downloaded for free from Circontrol Expert Area)


## C) IPSetup

1 - Connect the UTP Cable to the Computer (running Microsoft Windows, at least Windows XP) and the Ethernet Switch.

The Computer and the Charge Point must be in the same network and in the same range.




2 - Execute **IPSetup\_v21.exe** on the Computer.



3 - Choose between TCP1RS+ and TCP2RS+ depending on the type of Charge Point are you working with:

TCP1RS+: Charge Point working as a Satellite

TCP2RS+: Charge Point working as a Master




4 - Enter the following parameters and click on **'Configurar'**


- MAC of the Charge Point (see label on the side of the Charge Point)
- IP address
- Netmask
- Gateway: leave default settings

The image shows a configuration form with a '>>' button in the top right corner. The form contains four input fields: 'MAC' (empty), 'Dirección' (empty), 'Netmask' (pre-filled with '255 . 255 . 255 . 0'), and 'Gateway' (pre-filled with '0 . 0 . 0 . 0'). At the bottom of the form are two buttons: 'Configurar' (highlighted with a red dashed box) and 'Salir'.


5 - In case of TCPIRS+ please select Protocol "UDP", Port "10002" and Communication Speed "9600":



6 - Wait 30 seconds approximately until the process is complete.



7 - The process will complete when the following message appears, by clicking on 'OK' the setup web-page will open.





THIS PAGE HAS BEEN INTENTIONALLY LEFT BLANK

# 5

## Communications

### A) Introduction

This section describes how to install the SIM card and setting up the modem.

#### Modem location

The modem is installed inside the unit. Depending on the model, the modem is located in different place.



**Step 1-** Open Charge Point's door and locate the modem.

**Step 2-** Check that the Charge Point is provided with the antenna on the cover top.





**Modem is fully configured by default in Circontrol.  
Only in case it is needed to configure it, remain in this section.**

# B) Modem configuration

## 1 – MODEM OVERVIEW

The 4G modem installed from factory in the Charge Point is one of the **RUT24X series from Teltonika**.

This device allows to the Charge Point connects over 4G networks to remotely view or manage the Charge Point status. RUT24X series are compact mobile routers with high speed wireless and Ethernet connections.



|    |                                 |
|----|---------------------------------|
| 1  | LAN Ethernet port               |
| 2  | WAN Ethernet port*              |
| 3  | LAN Led indicator               |
| 4  | WAN Led indicator               |
| 5  | Power connector                 |
| 6  | Power LED                       |
| 7  | Signal strength indication LEDs |
| 8  | SIM card holder                 |
| 9  | WiFi antenna connector          |
| 10 | Reset button                    |
| 11 | LTE antenna connectors          |

(\* ) WAN Ethernet port is set up as a LAN Ethernet port in order not to disconnect modem from Charge Point during service issues.

## 2 – CONNECTION STATUS LED

Explanation of connection status LED indication:

- Signal strength status LED's turned on: router is turning on
- 2G, 3G and 4G LED's blinking every 1 sec: no SIM or bad PIN
- 2G/3G/4G LED's blinking every 1 sec: connected 2G/3G/4G, but no data session established
- Blinking from 2G LED to 4G LED repeatedly: SIM holder not inserted or access to network denied
- 2G/3G/4G LED turned on: connected 2G/3G/4G with data session
- 2G/3G/4G LED blinking rapidly: connected 2G/3G/4G with data session and data is being transferred.



### 3 – SIM CARD INSTALLATION

Insert SIM card which was given by your ISP (Internet Service Provider). Correct SIM card orientation is shown in the picture.



1. Push the SIM holder extract button
2. Pull out the SIM holder
3. Insert the SIM card
4. Push in the SIM holder


After installing the SIM card, check out that the 4G antenna (mobile), WiFi antenna and the power connector are properly attached.

**NOTE:** SIM card is not provided with equipment.

## 4 – LOGGING IN

After you're complete with the setting up as described in the section above, you are ready to start logging into your router and start configuring it.

This example shows how to connect through WiFi:




**For cibersecurity reasons, modem's WiFi connection is disabled by default.**

**In order to enable it, remember to adjust it in Charge Point side, as explained in section 6.**

4.1 Connect your ethernet cable in the LAN port and do all the settings being locally connected (it can also be done from the WAN port when WAN port is configured as a LAN).

4.2 At your service computer, look for access point named ChargePoint\_XXXXXXXXXX (where "X" means the serial number), and connect on it.




4.3 Open a web browser and type <http://192.168.1.1>, as shown in the front part of the modem.



Use the following parameters when prompted for authentication, and then either click Log in.

User name: **admin**; Password: **Admin001**

 **In order to change the password, remember to adjust it in Charge Point side, as explained in section 6.**

You have now successfully logged, from here on you can configure almost any aspect of your router.

4.4 **Configuration Wizard** will start after logging in. It is necessary to complete Configuration Wizard to setup modem to the correct mode.

Go to **Status** > **Network** > **Mobile** and pay attention to 'Sim card state' field, it has to be **Inserted**.

| MOBILE INFORMATION    |                 |
|-----------------------|-----------------|
| IMEI                  | 861107032412885 |
| SIM card state        | inserted        |
| IMSI                  | N/A             |
| ICCID                 | N/A             |
| Operator              | N/A             |
| Operator state        | Searching       |
| Cell ID               | N/A             |
| Data connection state | Disconnected    |
| Connection type       | 4G (LTE)        |
| Signal strength       | -40             |




Through the chapter, it is indicated when some features are able to be modified only in basic or standard mode.




**4.5 Network Mobile configuration.** Here you can configure mobile settings which are used when connecting to your local network.

Depending on the mode you are logged in, the screw flow is different:

- **Basic mode:**


Go to **Network > WAN > mob1sta1** > 



| ID | Name     | Status | Fallover | Type   | IP | Protocol            | Uptime | TX     | RX     | Action  |
|----|----------|--------|----------|--------|----|---------------------|--------|--------|--------|---|
| 1  | wan      | Down   | Disabled | -      | -  | dhcp                | -      | 0.00 B | 0.00 B |  |
| 2  | wan6     | Down   | Disabled | -      | -  | dhcpv6              | -      | 0.00 B | 0.00 B |  |
| 3  | mob1sta1 | Down   | Disabled | Mobile | -  | APN: Auto<br>SIM: 1 | -      | 0.00 B | 0.00 B |  |

**Auto APN (on) > save & apply**

Not necessary to type an APN.



INTERFACES: MOB1STA1

Mode: NAT

Auto APN:  ON

Connection is or will be established without using APN

MOBILE DATA LIMIT



Enable data connection limit:  OFF

[CLEAR COLLECTED DATA](#)



## Auto APN (off) > save & apply

Type the APN from your SIM provider in **Custom APN** field.




### NOTES:

1. If your SIM provider require any authentication ask them about what type, PAP or CHAP, select it on **Authentication method** field and introduce a password and username.
2. If you need to do some custom over the modem configuration, ask the Circontrol Support staff in order to get the Teltonika modem manual.


**- Advanced mode:**

Go to **Network > Interfaces > General > mob1s1a1** > 





**Auto APN (on) > save & apply**

Not necessary to type an APN.



## Auto APN (off) > save & apply

Type the APN from your SIM provider in **Custom APN** field.



### NOTES:

1. If your SIM provider require any authentication ask them about what type, PAP or CHAP, select it on **Authentication method** field and introduce a password and username.
2. If you need to do some custom over the modem configuration, ask the Circontrol Support staff in order to get the Teltonika modem manual.

4.6 In order to know if the connection has been done properly, check next steps:

Go to **Status > Network > Mobile** and pay attention to **Data connection state**, it has to be **"Connected"**

The screenshot shows the 'MOBILE INFORMATION' section of the Teltonika Networks web interface. The 'Data connection state' is highlighted with a blue box and a blue arrow pointing to it from the right. The 'Connection type' is listed as '4G (LTE)'.

| Parameter             | Value           |
|-----------------------|-----------------|
| IMEI                  | 861107032412885 |
| SIM card state        | inserted        |
| IMSI                  | N/A             |
| ICCID                 | N/A             |
| Operator              | N/A             |
| Operator state        | Searching       |
| Cell ID               | N/A             |
| Data connection state | connected       |
| Connection type       | 4G (LTE)        |

Go to **Status > Network > LAN > LAN information** and pay attention to IP addresses

The screenshot shows the 'LAN INFORMATION' section of the Teltonika Networks web interface. The 'DHCP LEASES' table is highlighted with a blue box and a blue arrow pointing to it from the right. The table shows a lease for 'repton-00000000' with IP address '192.168.1.216', MAC address '00:26:45:00:C4:02', and a lease time remaining of '11:29:51'.

| NAME | IP ADDRESS  | NETMASK       |
|------|-------------|---------------|
| lan  | 192.168.1.1 | 255.255.255.0 |


  

| HOSTNAME        | IP ADDRESS    | MAC ADDRESS       | LEASETIME REMAINING |
|-----------------|---------------|-------------------|---------------------|
| repton-00000000 | 192.168.1.216 | 00:26:45:00:C4:02 | 11:29:51            |


At **'DHCP Leases'** check that the modem has detected the automatic IP address and MAC number for both, your Service PC and the Charge Point.

**NOTES:**

1. If the modem has not detected the automatic IP address, switch off the circuit breaker, wait for 10 seconds and switch on again. Connect again your Service PC to the access point named ChargePoint\_XXXXXXXXXX, and repeat the steps 4.3 y 4.6.
2. To make sure that the Charge Point' s MAC number is correct, it can be seen in one label behind the HMI screen.



4.7 Go to **Network > Interfaces > Static Leases** (only in Advanced mode)



Complete the fields with next information:

Description – It can be written the name that you want for your Charge Point. It is highly recommended to name it keeping this structure: ChargePoint\_XXXXXXXXXX, to identify it easier.

MAC address – It will be the MAC number found behind the HMI screen, on the label

IP address – **192.168.1.50**

After filling the fields, push over **'Save & Apply'** button.

4.8 Disconnect the MCB inside the Charge Point in order to do a hard reset over the modem and the HMI screen, after 10 seconds switch ON again the MCB.

4.9 Repeat again the points 4.2 and 4.3 explained above:

4.2 – look for modem access point and connect on it.

4.3 – log on modem webpage with authentication.

4.10 Now, go again to **Status > Network > LAN > DHCP Leases** and confirm that the information written at the point 4.7 has been successfully recorded:

Description – the name given for Charge Point


MAC address – the MAC of the Charge Point

IP address – **192.168.1.50**

The screenshot shows the Teltonika Networks web interface. The left sidebar contains a navigation menu with categories: STATUS, System, Network, LAN, Services, and System. The main content area is titled 'TELTONIKA | Networks' and includes user information (MODE: BASIC, USER: ADMIN, FW VERSION: RUT2\_R\_00.07.03.1) and a LOGOUT button. Under 'LAN INFORMATION', there is a table with columns NAME, IP ADDRESS, and NETMASK. Below that, under 'DHCP LEASES', there is a table with columns HOSTNAME, IP ADDRESS, MAC ADDRESS, and LEASETIME REMAINING. The first row of the DHCP Leases table is highlighted with a blue box, and a blue arrow points to the MAC ADDRESS column.

| HOSTNAME | IP ADDRESS   | MAC ADDRESS       | LEASETIME REMAINING |
|----------|--------------|-------------------|---------------------|
| Raption  | 192.168.1.50 | 00:26:45:00:C4:02 | 11:29:51            |

#### 4.11 Go to **Network > Firewall > Port Forwards > Add new instance**



The ports that you can see in the table below are introduced in the modem by default, although only the named 50000 and 9191 are enabled:


| Name  | Protocol | External port (S) | Internal IP  | Internal port (S) |
|-------|----------|-------------------|--------------|-------------------|
| 80    | TCP      | 80                | 192.168.1.50 | 80                |
| 8080  | TCP      | 8080              | 192.168.1.50 | 8080              |
| 50000 | TCP      | 50000             | 192.168.1.50 | 50000             |
| 9191  | TCP      | 9191              | 192.168.1.1  | 80                |

If necessary, it is possible to enable the other ports or introduce them following the table listed above.


Push over **'Save & Apply'** button after any modification.



#### 4.12 Go to **Network > Firewall > Traffic Rules** (only in Advanced mode)




Roll down and look for 'Enable\_HTTP\_WAN' and 'Enable\_HTTPS\_WAN' fields and enable these.




Roll down again and push over '**Save & Apply**' button.

4.13 For ending with the modem logging is necessary to do a reboot:

Go to **System > Reboot** and push over the **'Reboot'** tab



During the process, the system will show the progress, do not switch off the modem.



4.14 Repeat again the points 4.2 and 4.3 explained above:


4.2 - look for modem access point and connect on it.

4.3 - log on modem webpage with authentication.

4.15 It is necessary to check that the Teltonika RUT24X LTE modem option is chosen at Charge Point's setup webpage:

Make sure that your Service PC is still connected with the Charge Point through wifi, open a web browser and type 192.168.1.50.

Go to **Configuration > Communications > General**



Click over the **'Save' button** located at the top right corner.

# 6


## Setup webpage



**Option only available to access in case of Master Charge Point.**


Setup webpage allows managing networking setup, upgrading devices and other options.

Once the Service PC is already connected to Charge Point, it is possible to open Setup Webpage through the IP entered. Open a web browser on the service PC and enter this IP, next image will appear.




The web-page opened shows the 'Dashboard' Overview' as a main screen, but there are many more options. In the next points, they will be explained.

### A) Dashboard



In the right top corner it is shown the search engine icon, the language list and information about the Charge Point. Once the info button is pressed, it appears the screen displayed above, with model and firmware version information, among others.


## COMMUNICATIONS



As a relevant information, it shows:

| Value       | Description  |
|-------------|--|
| IP          | Short for Internet Protocol. Identifier that allows information to be sent between devices on a network. |
| MAC Address | Identifier of the network card of the Charge Point   |

## CHARGE POINT




It is displayed if the Charge Point is available to be used or not.


# B) Monitor

In this section, it can be consulted the status of the Charge Point, the type of connectors it has and the availability of them.

It is possible to start or stop a charging session, able or disable a connector or lock or unlock it remotely.



It is also shown when connector individually has an internal error, and an error code, in order to look for the type of fault.



# C) Historic

This section provides information of every charge transaction started in the Charge Point.

It can be checked date and hour of begin and end of a charge transaction, energy charged, alias of the user and type of charge used.


All of this elements have the chance to be organized depending on the user needs.

The screenshot shows the 'Historic' page in the Circontrol interface. The page title is 'Historic (Last 7 days)'. There are search filters for 'Date range' and 'Identifier'. A table lists five charge transactions with columns for Begin date, End date, Charge time, Energy (kWh), Identifier, Plug, and Stop reason.

| Begin date          | End date            | Charge time | Energy (kWh) | Identifier | Plug   | Stop reason         |
|---------------------|---------------------|-------------|--------------|------------|--------|---------------------|
| 2021/08/10 09:17:33 | 2021/08/10 09:18:20 | a min       | 0.063        | USER1      | PLUG B | Vehicle disconnecte |
| 2021/08/10 09:18:05 | 2021/08/10 09:18:17 | a few s     | 0.000        | USER2      | PLUG A | Vehicle disconnecte |
| 2021/08/09 08:58:36 | 2021/08/09 08:58:48 | a few s     | 0.000        | USER3      | PLUG A | Vehicle disconnecte |
| 2021/08/09 08:33:42 | 2021/08/09 08:33:52 | a few s     | 0.000        | USER4      | PLUG A | Vehicle disconnecte |
| 2021/08/09 08:29:17 | 2021/08/09 08:29:28 | a few s     | 0.000        | USER5      | PLUG A | Vehicle disconnecte |

# D) Integrations

Clicking over the **'Integrations'** tab, user will be able to activate OCPP integrations.



**NOTE:** the integration of the Charge Point needs a separate chapter. In the next chapters number 6 and 7 it is explained how to integrate OCPP.




# E) Configuration


In this section, there can be adjusted many different settings related with the Charge Point, depending on the elements it has and level of security it is desirable to have.

## IDENTIFICATION METHOD

It is possible to enable or disable the option in order to use the Charge Point with or without identification, and also, if the user is capable to stop charge transaction.



When the Charge Point includes payment terminal, it is necessary to enable the option to let the user pay with this method.




Enable ChargeBox Id option allows the system to differentiate every single charge point separately, in order to use this data by the back end system.

As a Pre-authorisation amount, it can be configured the amount of money that the bank blocks to the user once the charge transaction starts. When the charge transaction is finished, the blocked fee is returned and only charge to the user according to the tariff described below.

Upload configuration allows to upload the configuration file with the payment gateway keys supplied by the specific financial service or bank. It can be downloaded the existing file whenever it is necessary.


## PLUGS





It is possible to choose charging with quick charging, slow charging or both, depending on the needs of the Charge Point.

**CHARGE:**

The Charge Point is capable of balancing the available power based on the number of outlets in use.





| Value                    | Description  |                          |        |      |    |                     |    |          |    |             |    |
|--------------------------|--|--------------------------|--------|------|----|---------------------|----|----------|----|-------------|----|
| Power Balance            | <p><b>ENABLE:</b> the Charge Point shares equally the power delivered to each ongoing Charge Transaction without exceeding the limit configured.</p> <p><b>DISABLED:</b> the Charge Point does not take in consideration any limit, giving the maximum power for each connector.</p>   |                          |        |      |    |                     |    |          |    |             |    |
| Profiles                 | <p>It lets to choose whether from the EV transaction and lock should be disconnected or not and choose the charging cable connection timeout in seconds.</p> <p>idTag option enabled adds a prefix indicating the method of identification chosen by the user, as shown in the table below:</p> <table border="1"> <thead> <tr> <th>Method of identification</th> <th>Prefix</th> </tr> </thead> <tbody> <tr> <td>RFID</td> <td>RF</td> </tr> <tr> <td>Contactless Payment</td> <td>CC</td> </tr> <tr> <td>PIN-code</td> <td>KC</td> </tr> <tr> <td>Plug&amp;Charge</td> <td>NA</td> </tr> </tbody> </table> | Method of identification | Prefix | RFID | RF | Contactless Payment | CC | PIN-code | KC | Plug&Charge | NA |
| Method of identification | Prefix   |                          |        |      |    |                     |    |          |    |             |    |
| RFID                     | RF   |                          |        |      |    |                     |    |          |    |             |    |
| Contactless Payment      | CC   |                          |        |      |    |                     |    |          |    |             |    |
| PIN-code                 | KC   |                          |        |      |    |                     |    |          |    |             |    |
| Plug&Charge              | NA   |                          |        |      |    |                     |    |          |    |             |    |





| Value               | Description   |
|---------------------|---|
| Shared power        | It indicates the power available to divide between the connected vehicles. The <i>Max.current supply (A)</i> is the available power <b>ONLY</b> for AC outlets. |
| OCPP-Smart Charging | The power balance is made via OCPP.   |

## COMMUNICATIONS

This section provides basic configuration of the network parameters.



DHCP server (router) means to enable or disable the IP address assignment. To be enabled when working with the integrated modems.




## HMI


Short for Human Machine Interface.

In this section, there can be adjusted many settings related with the Display.


In General tab it is possible to adjust screen brightness and enable or disable the email support and timeout. Also, in the Charge Point can be uploaded up to 20 languages between the wide variety able to choose.



Also, it is possible to customize the languages in the Charge Point. In the left column are all the available languages between the wide variety able to choose. On the other hand, in the right column are the ones chosen to be displayed in the Charge Point, organized as shown on screen.




In Screensaver tab it is possible to adjust timeout and brightness and enable or disable advertisements, what lets customize the Screensaver image by uploading a file.





## MASTER-SATELLITE

In this section, it is possible to synchronize new satellite Charging Points, that are linked to the one used as a Master.

To start the configuration, “Add charger” button should be clicked.




Then, a new field appears and the Charging Point you want to configure as a satellite should be chosen among the whole options in the table.



Depending on whether the model is DC or AC, it is shown in different way in the list above:

- DC: Only chance to choose eVolve Rapid Satellite model.
- AC: It consists in a 25-digit configuration code. There are **5 parameters that can change**, depending on the model specifications.





Using the code in the image as an example, there are these exchangeable parameters.

|  |
|--|
| XXXXXX <b>64</b> xx <b>53</b> xx <b>2</b> xxxxxx.rev <b>0</b>  |
| XXXXXX <b>AA</b> xx <b>BC</b> xx <b>DD</b> xxxxxx. <b>EEEE</b> |

The multiple options for each parameters are described in the following table:

| Value            | Options | Description  |
|------------------|---------|--|
| AC Current (AA)  | 64      | AC input current. (32A + 32A)  |
| AC inputs (B)    | 1       | T2S32 version.   |
|                  | 3       | T1C32 version.   |
|                  | 5       | T2C32 version.   |
|                  | 6       | T2S32 version. (With shutter)  |
| Phases (C)       | 1       | Single-phase charging point.   |
|                  | 3       | Three-phase charging point.  |
| Tamper (DD)      | --      | Without tamper.  |
|                  | 2x      | With tamper.   |
| Connector (EEEE) | rev0    | Cable or one of the following covers<br> |
|                  | rev2    |   |

## TARIFFS

In this section, it can be adjusted the cost of a charge transaction. These settings are just displayed to inform the customer.

**It is necessary to work with an integrated system for the payment, such as contactless payment kit or OCPP Integrations.** The payment will be done through one of these platforms.

When adjusting these settings, they will be displayed in the charger screen even if there is not a platform in charge of the receipt. Make sure that values are set according to the final price from these platforms.

Remember to press 'Save button to apply the settings.


| Description       | Price | Units | Enabled |
|-------------------|-------|-------|---------|
| Fixed service fee | 1     | €     | Enabled |
| Energy fee        | 1     | €/kWh | Enabled |
| Time fee          | 1     | €/min | Enabled |

There are few parameters that can be adjusted:

| Value             | Description   |
|-------------------|---|
| Currency          | Choose the proper currency according to the area the Charge Point is installed. |
| Price Limit       | Maximum cost of the charge transaction.   |
| Fixed service fee | Price of a new charge transaction.  |
| Energy fee        | Amount of money to be payed based on the energy delivered to the EV.            |
| Time fee          | Amount of money to be payed based on the duration of charge transaction.        |

All these settings can be combined according to the customer preferences.

## SECURITY



| Value                         | Description  |
|-------------------------------|--|
| Allow only secure connections | <p><b>ENABLE:</b> Information transferred between Charge Point and laptop is strictly encrypted. Once enabled, it must be done some modifications in modem configuration, as explained below.</p> <p><b>DISABLED:</b> not possible to assure secure connections between Charge Point and laptop.</p> |
| Authentication                | <p><b>ENABLE:</b> Introduce a user and a password in order to enter in the web setup.<br/>NOTE: Old password is 1234 by default.</p> <p><b>DISABLED:</b> not password required to enter in the websetup.</p> <p>It is possible this option to be changed whenever is desired.</p>                    |


## Configure modem to allow secure connections:



After you're complete with the setting up as described in the section 5, you are ready to start logging into your router and start configuring it.

### 1. Go to **Network > Firewall > Port Forwards**


Locate the port named "Enable\_HTTPS\_WAN\_PASSTHROUGH" and click  button.



The screenshot shows the 'PORT FORWARDS' configuration page. A table lists several rules. The rule 'Enable\_HTTPS\_WAN\_PASSTHROUGH' is highlighted with a blue box. A blue arrow points to the edit icon (a pencil) for this rule. Below the table is an 'ADD NEW INSTANCE' form with fields for NAME, EXTERNAL PORT, INTERNAL IP ADDRESS, and INTERNAL PORT.

| NAME                         | MATCH  | FORWARD TO                      | STATUS | ACTIONS         |
|------------------------------|--|---------------------------------|--------|-----------------|
| -                            | IPV4 tcp<br>From any host in wan<br>Via any router IP                  | IP 192.168.1.1 in lan           | ON     | [edit] [delete] |
| -                            | IPV4 tcp, udp<br>From any host in wan<br>Via any router IP             | IP 192.168.1.1 in lan           | ON     | [edit] [delete] |
| 8                            | IPV4 tcp, udp<br>From any host in wan<br>Via any router IP at port 81  | IP 192.168.1.1, port 81 in lan  | ON     | [edit] [delete] |
| -                            | IPV4 tcp, udp<br>From any host in wan<br>Via any router IP             | IP 192.168.1.1 in lan           | ON     | [edit] [delete] |
| -                            | IPV4 tcp, udp<br>From any host in wan<br>Via any router IP             | IP 192.168.1.50 in lan          | ON     | [edit] [delete] |
| Enable_HTTPS_WAN_PASSTHROUGH | IPV4 tcp, udp<br>From any host in wan<br>Via any router IP at port 443 | IP 192.168.1.1, port 443 in lan | ON     | [edit] [delete] |

Once in Edit screen, insert 192.168.1.50 in "Internal IP address" field and click Save & Apply button.



The screenshot shows the 'Edit' screen for the 'Enable\_HTTPS\_WAN\_PASSTHROUGH' rule. The 'Internal IP address' field is highlighted with a blue box and contains the value '192.168.1.50'. The 'Save & Apply' button is visible at the bottom right.

## 2. Go to **Network > Firewall > Port Forwards**

At the bottom part of the screen, add a new port forward rule with the following parameters and once introduced click Add button:

Name: Enable\_HTTPS\_WAN\_OCPP

External port: 8443

Internal IP Address: 192.168.1.50

Internal port: 8443

ADD NEW INSTANCE

|   |                                    |   |                                    |                                 |
|---|------------------------------------|---|------------------------------------|---------------------------------|
| <small>NAME</small><br>New port forward | <small>EXTERNAL PORT</small><br>80 | <small>INTERNAL IP ADDRESS</small><br>192.168.1.1 (Teltonika RUT240 core) | <small>INTERNAL PORT</small><br>80 | <small>ADD</small>              |
|   |                                    |   |                                    | <small>SAVE &amp; APPLY</small> |

Check that the new line appears and switch to **ON** position to enable it.


The screenshot shows the 'PORT FORWARDS' configuration page in the Teltonika Networks web interface. The page title is 'PORT FORWARDS' and it includes a table with columns for NAME, MATCH, and FORWARD TO. The table contains several rules, with the 'Enable\_HTTPS\_WAN\_OCPP' rule highlighted in blue. The status of this rule is 'ON'.


| NAME                  | MATCH   | FORWARD TO                        | STATUS | ACTIONS |
|-----------------------|---|-----------------------------------|--------|---------|
| -                     | IPv4 tcp<br>From any host in wan<br>Via any router IP                   | IP 192.168.1.1 in lan             | OFF    | ON/OFF  |
| -                     | IPv4 tcp, udp<br>From any host in wan<br>Via any router IP              | IP 192.168.1.1 in lan             | OFF    | ON/OFF  |
| *                     | IPv4 tcp, udp<br>From any host in wan<br>Via any router IP at port 81   | IP 192.168.1.1, port 81 in lan    | OFF    | ON/OFF  |
| -                     | IPv4 tcp, udp<br>From any host in wan<br>Via any router IP              | IP 192.168.1.1 in lan             | OFF    | ON/OFF  |
| -                     | IPv4 tcp, udp<br>From any host in wan<br>Via any router IP at port 442  | IP 192.168.1.50, port 442 in lan  | OFF    | ON/OFF  |
| Enable_HTTPS_WAN_OCPP | IPv4 tcp, udp<br>From any host in wan<br>Via any router IP at port 8443 | IP 192.168.1.50, port 8443 in lan | ON     | ON/OFF  |

At the bottom of the page, there is an 'ADD NEW INSTANCE' form with the following fields:


- NAME:** New port forward
- EXTERNAL PORT:** 80
- INTERNAL IP ADDRESS:** 192.168.1.1 (Teltonika RUT240 core)
- INTERNAL PORT:** 80
- Buttons:** ADD, SAVE & APPLY

3. Go to **Network > Firewall > Traffic Rules** (only in Advanced mode)

Locate the rule named "Enable\_ HTTPS\_WAN" and click  button.



Once in Edit screen, insert 192.168.1.50 in "Destination address" field and 443 in "Destination port" field; then click Save & Apply button.



4. Go to **Network > Firewall > Traffic Rules** (only in Advanced mode)

At the bottom part of the screen, add a new traffic rule with the following parameters and once introduced click Add button:

Name: OCPP  
 Protocol: All  
 Destination address: 192.168.1.50  
 Destination port: 8443

Check that the new line appears and switch to **ON** position to enable it.


Then click  button.

Once in Edit screen, insert TCP+UDP in "Protocol" field and then click Save & Apply button.

# F) Maintenance

## DEVICES STATUS

In this section, it can be consulted the status of the devices which are communicating via RS-485.




The screenshot shows the 'Maintenance' section of the Circontrol interface. The left sidebar contains a menu with 'Maintenance' selected and 'Devices status' highlighted. The main content area is titled 'Maintenance Devices status' and displays a table of device statuses.

| Device name     | Status |
|-----------------|--------|
| EVSE            | Ok     |
| Serial          | Ok     |
| Plug A - Mode 3 | Ok     |
| Plug B - Mode 3 | Ok     |
| Plug A - Meter  | Ok     |
| Plug B - Meter  | Ok     |
| Display         | Ok     |
| Serial 2        | Ok     |
| Reader          | Ok     |

## UPDATES

Through this tab, the Charge Point firmware and the application can be upgraded remotely.



The screenshot shows the 'Maintenance Updates' section of the Circontrol interface. The left sidebar contains a menu with 'Maintenance' selected and 'Updates' highlighted. The main content area is titled 'Maintenance Updates' and displays two update sections: 'Firmware update' and 'Configuration update'.

**Firmware update**

Upload file:

Summary

Build creation date: 2021-06-04 09:36:02

Firmware version: 3.0.1-rc2

**Configuration update**

Upload file:






**To obtain the latest firmware version or need any special configuration update, please contact CIRCONTROL Support Department.**

## DIAGNOSTICS

Clicking over the **'HW Testing'** tab, it appears to enable or disable Grid test option.


That means HMI shows a test screen to check that touch function works properly.



The logs shown in this section are automatically produced by the Charge Point. It is a detailed list of the charging sessions, system performance or user activities.

When Charge Point is powered ON, system begins to register log files. If the Charge Point is restarted these logs are lost and immediately are created new ones.

However, it is highly recommended to check log files in the next URL: <http://IPADDRESS/services/cpi/log>



## SYSTEM STATUS

The information shown in this section is basically relative to the state of the PC of the Charge Point. It is necessary for the technical service staff but does not show any information regarding to the external connection of the Charge Point or to the charging session.

**Maintenance**  
System status

Memory MB      CPU %      Disk MB

Uptime 21h 27m 32s

**Drivers**

|                             |                    |                   |
|-----------------------------|--------------------|-------------------|
| - A8 Embedded               | - CBS-4            | - CBS-8           |
| - CCL1 Engine               | - CEM-C10          | - CEM-C20         |
| - CEM-C30                   | - CHARGEDEMO       | - CVM-1D          |
| - CVM-MINI                  | - CVM-NRG96        | - Comms simulator |
| - Display CCL1              | - Display CCL1Mini | - EDMk            |
| - Ingelico Payment Terminal | - LM-4             | - M1CD            |
| - M3CD                      | - Mode 4 DELTA     | - Mode 4 LITE     |
| - Mode 4 PRE                | - Power Supervisor | - RS232/485       |
| - SLAVESMARTREADER          | - SMARTMETER       | - TCP1RS-Plus     |
| - TCP2RS                    | - TCP2RS ModbusTCP | - TCP2RS TCP      |
| - TCP2RS-Plus               | - TWNSREADER       | - Tag reader      |

## ADVANCED

This section allows setting the time and region time for the Charge Point. Also, it offers the possibility to reset the Charge Point.

**Maintenance**

Time zone: UTC

Device time: Synchronise clock 12/08/2021 06:54:42

Primary NTP server: Primary NTP server

Secondary NTP server: Secondary NTP server

**Reset**

Choose Type

Soft      Hard

Next, we will explain the different sections of the '**Date and time**' and '**Reset**'

| <b>Value</b>         | <b>Description</b>   |
|----------------------|--|
| Time Zone            | Select the regional time for the Charge Point according to the location.   |
| Time                 | Current date and time of the Charge Point.   |
| Primary NTP Server   | Synchronize the time through internet automatically.   |
| Secondary NTP Server |  |
| Soft Reset           | Restart of the Charge Point, closing applications and clearing any data in RAM. Unsaved data in current use may be lost but data stored on the hard drive, applications and settings are not affected. |
| Hard Reset           | Also known as a factory reset or master reset, is the restoration of the Charge Point to the state it was in when it left the factory.   |

# 7

## OCPP 1.6J

---

### A) Introduction

The goal of the Open Charge Point Protocol (OCPP) is to offer a uniform solution for the communication between Charge Point and a Central System. With this open protocol it is possible to connect any Central System with any Charge Point, regardless of the vendor.


Follow next steps in order to configure OCPP 1.6 in the Circontrol Charge Points.

## B) Before starting

Check following steps in order to ensure the correct function of OCPP 1.6:


Go to the **Setup Web-page** > **'Integrations'** tab > **'General'** tab

Once in **'General'** section, Public IP source establishes where the Charge Point must obtain the public IP address in order to send it later to the back-end. Different values can be selected:



Choose the option selected under **'Public IP source'** according to your network topology.

When done, please do not forget to save changes using **'Apply'** button just below the option selected.




# c) Configuration

Go to the **Setup Webpage** > **'Integrations'** tab > **'General'** tab

Charge Point supports different versions of OCPP but only one can be enabled at the same time.

Go back to setup web page and click on the **'Integrations'** tab, choose the option selected under **'Available integrations'** according to your back-end policies as shown in the picture:




**NOTE:** Charge Point is working as stand-alone if **'none'** option is selected. All ID cards are authorized to start/stop a new charge transaction and no requests are sent to the back-end.

| <b>Value</b>         | <b>Description</b>   |
|----------------------|--|
| Charge Point ID      | Charge Point identifier.   |
| Basic Authentication | Set an authentication if required, being the options 'Enabled' and 'Disabled'. |
| Connection URL       | URL address of the central system.   |
| CS-Password          | Introduce CS-Password if required.   |

Go to the **Setup Web-page > Integrations > 'Settings'** tab

Once OCPP 1.6 option is selected, a link appears allowing access to the OCPP configuration.


Please, click on the link button as shown in the picture:






| Value   | Description  |
|---|--|
| Use OCPP time synchronization                   | <p><b>ENABLED:</b> Synchronization of date and time.</p> <p><b>DISABLED:</b> Synchronization of date and time.</p> <p><b>*NOTE:</b> Date and Time is sent from backend on each heartbeat response.</p> |
| Energy for metervalues                          | <p><b>PARTIAL:</b> Sends partial energy consumption while vehicle is charging.</p> <p><b>TOTAL:</b> sends the actual count of the total accumulated energy meter.</p>                                  |
| ID tag endianness                               | Storage type for system data ( <b>BIG</b> or <b>LITTLE</b> ).  |
| Energy for Start/ Stop transaction              | <p><b>PARTIAL:</b> Consumed value of energy by the vehicle sent between start and stop.</p> <p><b>TOTAL:</b> Actual count of the total accumulated energy meter sent between start and stop.</p>       |
| User confirmation required to start transaction | <p><b>ENABLED:</b> user confirmation needed to proceed with a remote start (i.e. touch the screen).</p> <p><b>DISABLED:</b> user confirmation NOT needed to proceed with a remote start.</p>           |
| Send metervalues only while charging            | Choose between ( <b>ENABLED</b> or <b>DISABLED</b> ).  |
| Log capture level                               | Level of information detailed ( <b>DEBUG</b> > <b>INFO</b> > <b>ERROR</b> > <b>NONE</b> ).   |


Go to the **Setup Web-page > Integrations > 'SSL certificates'** tab



For WSS connections is needed a Central System certificate. Upload it in this section.




Go to the **Setup Web-page** > **Integrations** > **'Configuration keys'** tab



| Value                           | Description  |
|---------------------------------|--|
| Authorisation cache             | <p><b>ENABLED:</b> maintain a local list of all presented identifiers that have been successfully authorized by the Central System.</p> <p><b>DISABLED:</b> authorization for presented identifiers is requested directly to the Central System.</p> |
| Authorise remote Tx requests    | <p><b>ENABLED:</b> the Charge Point asks for authorization when the Central System sends a remote start.</p> <p><b>DISABLED:</b> the Charge Point starts the Charge Transaction when the Central System sends a remote start.</p>                    |
| Local pre- authorisation        | <p><b>ENABLED:</b> Charge Point looks for locally-authorized identifiers without waiting for the Central System authorization.</p> <p><b>DISABLED:</b> Charge Point requests authorization for presented identifiers to the Central System.</p>      |
| Allow offline Tx for unknown ID | <p><b>ENABLED:</b> during offline period unknown identifiers are allowed to start charging.</p> <p><b>DISABLED:</b> during offline period unknown identifiers are NOT allowed to start charging.</p>   |


| Value                              | Description   |
|------------------------------------|---|
| Local authorisation off-line       | <p><b>ENABLED:</b> during offline period locally-authorized identifiers are allowed to start charging.</p> <p><b>DISABLED:</b> during offline period locally-authorized identifiers are NOT allowed to start charging.</p>      |
| Stop transaction on invalid ID     | <p><b>ENABLED:</b> stop existing Charge Transaction after response from Central System when user is blocked, expired or invalid.</p> <p><b>DISABLED:</b> Charge Transaction does not stop even if backend rejects the user.</p> |
| Metervalue (select one or more)    | List of supported values used in the MeterValue.  |
| Transaction message retry interval | <p>Number of seconds between transaction message attempts.</p> <p><b>*NOTE:</b> setting this value to 0 disables the attempts.</p>  |
| Transaction message attempts       | How many times the Charge Point should try to send a request to the Central System.   |
| Heartbeat interval                 | <p>Number of seconds between Heartbeats.</p> <p><b>*NOTE:</b> setting this value to 0 disables the Heartbeat.</p>   |
| Metervalues sample interval        | <p>Number of seconds between MeterValue during an ongoing Charge Transaction.</p> <p><b>*NOTE:</b> setting this value to 0 disables the MeterValue.</p>   |
| WebSocket ping interval            | <p>Number of seconds between Pings.</p> <p><b>*NOTE:</b> setting this value to 0 disables the Websocket Ping/Pong.</p>  |

Go to the **Setup Web-page** > **Integrations** > **'Backup'** tab



It is possible to download a backup of the Charge Point pressing 'Download setup' button. On the other hand, it can also be uploaded a backup previously downloaded from another Charge Point.

Go to the **Setup Web-page** > **Integrations** > **'Security'** tab



In this chapter could be introduced a user and password in order to enter in this section. It is possible this option to be changed whenever is desired.

**NOTE:** Old password is 1234 by default.

# 8

## Monitoring

---

### SCADA Client

The IP address assigned previously, is useful to connect with the Charge Point in order to monitor the real-time status.

The main way to connect is using the **CirCarLife client software** (Supplied by Circontrol Support staff) or you can download it from Circontrol Expert Area Webpage.

**NOTE:** Java software needs to be installed on your computer in order to run the client software, please, download last version from: [www.java.com](http://www.java.com)



**In remote connections, where is required communicate via 3G/4G data with the Charge point in order to monitor its parameters, it should be noted that there will be a HIGH consumption of data.**



CCL1Engine - PowerStudio Scada

Options Views General





Previous Next Devices Graph Table Events Properties Print

CCL1Engine 4/8/13 1:44:22 PM





Bollard state

|         |   |       |     |
|---------|---|-------|-----|
| Leakage | ✓ | Reset | OFF |
| Tamper  | ✓ |       |     |
| Tilt    | ✓ |       |     |

PLUG A

|                |   |                             |   |
|----------------|---|-----------------------------|---|
| Status         |  Available   | Charge relay                |  |
| Car connected  |              | Active energy (kWh)         | 535,440   |
| Connector lock |  Lock Unlock | Partial active energy (kWh) | 0,000   |
| Reserved       | 0 Reserve Release   | Charge request date         |   |
| Charge         | Remote start Remote stop Paused   | Charge begin date           |   |
| Enable         | Enable Disable  | Charge end date             |   |
| Leakage        | ✓ Reset OFF   | Charge time                 |   |
|                |   | Last charge stop            | Stopped by user   |

PLUG B

|                |   |                             |   |
|----------------|---|-----------------------------|---|
| Status         |  Available    | Charge relay                |  |
| Car connected  |              | Active energy (kWh)         | 45,440  |
| Connector lock |  Lock Unlock | Partial active energy (kWh) | 0,000   |
| Reserved       | 0 Reserve Release   | Charge request date         |   |
| Charge         | Remote start Remote stop Paused   | Charge begin date           |   |
| Enable         | Enable Disable  | Charge end date             |   |
| Leakage        | ✓ Reset OFF   | Charge time                 |   |
|                |   | Last charge stop            | Stopped by user   |

## 9

# Technical data

## A) AC Charge

### General Specifications

|                                    |   |
|------------------------------------|---|
| <b>Enclosure rating</b>            | IP54 / IK10                                     |
| <b>Enclosure material</b>          | Aluminium & ABS                                 |
| <b>Enclosure door lock</b>         | Anti-vandal key                                 |
| <b>Enclosure access</b>            | Frontal door                                    |
| <b>Operating temperature</b>       | -5 °C to + 45 °C                                |
| <b>Ambient temperature storage</b> | -20 °C to + 60 °C                               |
| <b>Operating humidity</b>          | 5% to 95% Non-condensing                        |
| <b>Meter</b>                       | MID Class 1 – EN50470-3                         |
| <b>Light beacon</b>                | RGB colour indicator                            |
| <b>Power limit control</b>         | Mode 3 PWM control according to ISO/IEC 61851-1 |
| <b>Dimensions</b>                  | 450 x 290 x 1550 mm                             |
| <b>Weight</b>                      | 55 kg   |
| <b>Power Output Management</b>     | Integrated Load Management                      |
| <b>Overcurrent protection</b>      | MCB (Curve C)                                   |
| <b>Safety protection</b>           | RCD Type A (30mA)                               |
| <b>Type 2 socket protection</b>    | Locking System                                  |

#### Master

|                           |   |
|---------------------------|---|
| <b>Network connection</b> | 10/100TX (TCP-IP)   |
| <b>Interface protocol</b> | OCPP 1.6J / 2.0 HW Ready  |
| <b>Display HMI</b>        | 8" anti-vandal touchscreen  |
| <b>RFID Reader</b>        | ISO/IEC 14443 A/B<br>MIFARE Classic/DESFire EV1<br>ISO 18092 ECMA-340<br>NFC 16.53MHz |

#### Satellite

|                             |              |
|-----------------------------|--------------|
| <b>Master Communication</b> | Ethernet UTP |
|-----------------------------|--------------|

| Optional devices  |   |
|---|---|
| <b>Low Temperature Kit</b>                                  | -30 °C to +45 °C  |
| <b>Safety Protection</b>                                    | RCD Type A + 6mA DC<br>RCD Type B (30mA)                            |
| <b>Surge Protection</b>                                     | Four pole transient surge protector IEC 61643-1 (class II)          |
| <b>Type 2 socket protection</b>                             | Shutter   |
| <b>Wireless communication</b><br>(only available in Master) | EMEA - 4G LTE/WiFi Hotspot/GPRS/GSM<br>LATAM/APAC - 4G LTE/GPRS/GSM |
| <b>Tethered cable (spring)</b><br><b>(cable length: 4m)</b> | Type 1 + Type 1<br>Type 2 + Type 2                                  |
| <b>Network hub</b><br>(only available in Master)            | Switch TCP ethernet 8 ports<br>Switch TCP ethernet 12 ports         |
| <b>RFID Extension</b>                                       | Legic Advant / Legic Prime<br>ISO 15693 / ISO 18092, Sony FeliCa    |
| <b>Customisation</b>  | Frontal Labelling   |
| <b>Contactless payment*</b>                                 | Integrated credit card payment terminal                             |

\* As an optional

| Models                        | Master or Satellite<br>S       | Master or Satellite<br>T       |
|-------------------------------|--------------------------------|--------------------------------|
| <b>AC power supply</b>        | 1P + N + PE                    | 3P + N + PE                    |
| <b>AC input voltage</b>       | 230 VAC +/-10%                 | 400 VAC +/-10%                 |
| <b>Maximum input current</b>  | 64 A                           | 64 A                           |
| <b>Maximum input power</b>    | 14.8 kW                        | 44 kW                          |
| <b>Number of plugs</b>        | 2                              | 2                              |
| <b>Maximum output current</b> | 32 A                           | 32 A                           |
| <b>Maximum output power</b>   | 7.4 kW                         | 22 kW                          |
| <b>AC output voltage</b>      | 230 VAC (1P + N + PE)          | 400 VAC (3P + N + PE)          |
| <b>Maximum output current</b> | 32 A                           | 32 A                           |
| <b>Maximum output power</b>   | 7.4 kW                         | 22 kW                          |
| <b>AC output voltage</b>      | 230 VAC (1P + N + PE)          | 400 VAC (3P + N + PE)          |
| <b>Master</b>                 | 2x Type 2 Socket (lock system) | 2x Type 2 Socket (lock system) |
| <b>Satellite</b>              | 2x Type 2 Socket (lock system) | 2x Type 2 Socket (lock system) |

# B) DC Charge

## General Specifications

|                                       |   |
|---------------------------------------|---|
| <b>AC Power Supply</b>                | 3P + N + PE   |
| <b>AC Input Voltage</b>               | 400V +/- 10%<br>three-phase   |
| <b>Power Factor</b>                   | > 0.98  |
| <b>Efficiency</b>                     | 94% at nominal output power   |
| <b>Frequency</b>                      | 50 / 60Hz   |
| <b>Required power supply capacity</b> | 27 kVA  |
| <b>Maximum AC input current</b>       | 39 A  |
| <b>Maximum output power</b>           | 25 kW   |
| <b>Maximum output current</b>         | 70 A  |
| <b>Output voltage</b>                 | 150-920 Vdc   |
| <b>Compliance</b>                     | CE / Combo-2<br>(DIN 70121; ISO15118)<br>IEC61851-1; IEC61851-23<br>IEC61851-21-2 |
| <b>Enclosure material</b>             | Aluminium & ABS   |
| <b>Enclosure rating</b>               | IP54 & IK10   |
| <b>Operating Humidity</b>             | Up to 95%   |
| <b>Ambient temperature storage</b>    | -40 °C to +60 °C  |
| <b>Lights for status indication</b>   | RGB colour indicator  |
| <b>Enclosure door lock</b>            | Security key lock   |
| <b>Enclosure access</b>               | Frontal door  |
| <b>Charge cable length</b>            | 5.5 meters  |
| <b>MID</b>                            | Class 1 - EN50470-3   |

### Master

|                                   |   |
|-----------------------------------|---|
| <b>Network connection</b>         | 10/100TX (TCP-IP)   |
| <b>Interface protocol</b>         | OCPP 1.6J / 2.0 HW Ready  |
| <b>Display HMI</b>                | 8" anti-vandal touchscreen  |
| <b>RFID Reader</b>                | ISO/IEC 14443 A/B<br>MIFARE Classic/DESFire EV1<br>ISO 18092 ECMA-340<br>NFC 16.53MHz |
| <b>Wireless communication</b>     | EMEA - 4G LTE/WiFi<br>Hotspot/GPRS/GSM  |
|                                   | (only available in Master)  |
| <b>Network hub RFID Extension</b> | Switch TCP ethernet 8 ports   |
|                                   | (only available in Master)  |

### Satellite

|                             |              |
|-----------------------------|--------------|
| <b>Master Communication</b> | Ethernet UTP |
|-----------------------------|--------------|





## Optional devices

|   |  |
|---|--|
| <b>Wireless communication</b><br>(only available in Master)     | LATAM/APAC – 4G LTE/GPRS/GSM                                     |
| <b>Network hub RFID Extension</b><br>(only available in Master) | Switch TCP ethernet 16 ports                                     |
| <b>RFID Extension</b>   | Legic Advant / Legic Prime<br>ISO 15693 / ISO 18092, Sony FeliCa |
| <b>Contactless payment*</b>                                     | Integrated credit card payment terminal                          |
| <b>Safety Protections**</b>                                     | RCD type B 30mA<br>MCB curve C                                   |

\* Ask for availability

\*\* Only in Wallbox model

## Model Specifications

| Models                            | Post Master/<br>Satellite  | Wallbox<br>Satellite   |
|-----------------------------------|--|--|
| <b>Safety Protections</b>         | RCD type B 30mA<br>MCB curve C   | -  |
| <b>Operating Temperature</b>      | -25°C to +45°C<br>(Low Temp. Kit)  | -5°C to +45°C  |
| <b>Environment</b>                | Outdoor / Indoor   | Indoor   |
| <b>Dimensions<br/>(W x H x D)</b> | 479 x 1750 x 288 mm  | 382 x 984 x 236 mm   |
| <b>Weight</b>                     | 77 kg  | 56 kg  |
| <b>Cable support</b>              | Integrated connector holder and cable roller   | Cable roller   |
| <b>Connection</b>                 | CCS2<br><br> | CCS2<br><br> |



## **Need help?**

---

In case of any query or need further information, please contact our **Support Department**



[support@circontrol.com](mailto:support@circontrol.com)



[www.circontrol.com](http://www.circontrol.com)



(+34) 937 362 940



(+34) 937 362 941



**CIRCONTROL  
Master-Satellite  
USER MANUAL**

A comprehensive guide on  
how to use and configure your  
Master-Satellite solution.

**V5.0, May edition 2023**